




ELANDA 140&160

A x1		B x1	
C x1		D x1	
E x2		F x1	
G x1		H x2	
I x4		J x2	
K x6		L x4	
M x22		P x16	



HALMAR Sp. z o.o.
 ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
 tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl

ELANDA 140&160




Q x 39






R x 4




S x 2




5






6



7



8



HALMAR Sp. z o.o.

ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
 tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl